1882010
Photo Storage End Table

Parts and Hardware List

A.	Top Assembly	1 pc
B.	Legs	4 pcs

* Please make sure that you have all the parts indicated above before you begin assembly of this item.
* This item should be assembled on a soft surface to prevent scratching the finish during assembly.
* This item may require periodic tightening**.**

Assembly Instruction

1. **Attach Legs (B)** Place the Top Assembly (A) upside down on a soft surface. Align the exposed threads of the Legs (B) with the pre-threaded holes in the Top Assembly (A). Secure the legs in place by turning in a clockwise direction. If the Legs (B) are out of alignment after they are tight, turn until they sit in the correct position as shown in illustration. **Note: Be careful not to over tighten the Legs (B).**